

P.S.I. RETROFIT KITS



Quantity Per Tandem Kit	Components
1	CONTROL BOX WITH LID
1	CONTROL BOX BRACKET
BULK	AIR TUBING
BULK	ELECTRICAL CABLE
BULK	NYLON TIE STRAPS
1	TRAILER LIGHT WITH HARDWARE
4	THROUGH-TEES WITH FLAPPERS AND SHIELDS
4	STATORS
4	PRESS PLUGS WITH ADHESIVE AND TOWELETTES
4	FLEX HOSES FOR INSIDE TIRE
4	FLEX HOSES FOR OUTSIDE TIRE
1	PRESSURE PROTECTION VALVE
1	MISC. FITTING AND HARDWARE KIT

HOW TO SPECIFY RETROFIT KITS:

1. DETERMINE AXLE MANUFACTURER AND SPINDLE STYLE - STRAIGHT OR TAPERED. IF THE AXLE WAS MTIS PREPPED AT FACTORY, USE MTIS PREPPED KIT (LESS PRESS PLUGS AND STATORS)
2. IDENTIFY WHEEL SIZE AND DETERMINE AXLE COUNT. USE THE CHARTS BELOW TO SELECT THE CORRECT RETROFIT KIT
3. SEE PREVIOUS PAGE TO SELECT THE APPROPRIATE STYLE OF HUBCAPS (HUBCAPS INCLUDED IN FULL THERMALERT™ KITS)
4. DETERMINE HUB MATERIAL - DUCTILE IRON OR ALUMINUM

NOTE: ALL RETROFIT KITS ARE PRE SET TO 100P.S.I., PLEASE CONSULT THE MTIS MAINTENANCE & INSTALLATION MANUAL FOR DETAILS

RETROFIT KIT SERIES

STRAIGHT SPINDLE

31955 SERIES	HOLLAND PROPAP
31975 SERIES	MERITOR TP, TB (1998 AND LATER), WP, HENDRICKSON HP-2.75"
32405 SERIES	MERITOR TB (BEFORE 1998) - 2.95"
32595 SERIES	SUDISA 12-R
32815 SERIES	DANA P22, HENDRICKSON HP-2.50"
61151 SERIES	MERITOR TL-2.50"
H1975 SERIES	THERMALERT™ FOR MERITOR TP, TB (1998 AN LATER), WP, HENDRICKSON-2.75"

TAPERED SPINDLE

31924 SERIES	DANA/EATON® D22 SOLID SPINDLE
31935 SERIES	INGERSOLL® F22
31965 SERIES	MERITOR TN/TQ, RN/RQ, HENDRICKSON HN, DANA/EATON D22 HOLLOW SPINDLE
32375 SERIES	HOLLAND TRADE
32645 SERIES	SUDISA 11-M
H1965 SERIES	THERMALERT™ FOR MERITOR TN/TQ, RN/RQ, HENDRICKSON HN, DANA/EATON D22 HOLLOW SPINDLE

MTIS PREPPED AXLES

32712 SERIES	ALL MANUFACTURERS (DOES NOT INCLUDE PRESS PLUGS AND STATORS)
H2712 SERIES	THERMALERT™ FOR ALL MANUFACTURERS (DOES NOT INCLUDE THERMALERT™ PRESS PLUGS AND STATORS)