



EBERHARD LOCKRODS & PARTS

NEW STYLE



Item	Part Number	Description
1	1977-35-13	CAM
2	1979-1-13	KEEPER
	1-1979-SSC1-22	KEEPER S/S
3	1979-10-13	BEARING COVER
4	1979-18-01	PLASTIC BEARING LINER UPPER
5	1979-19-01	PLASTIC BEARING LINER LOWER
6	1979-8-13	LOCKROD BRACKET 4 HOLE
	1979-9-13	LOCKROD BRACKET 2 HOLE
7	1969-7-13	HANDLE RETAINER
8	1969-4X-13	HANDLE KEEPER
9	GD1969-6XL	HANDLE LH W/ LOGO
	GD1969-6XR	HANDLE RH W/ LOGO
	1969-6X-13	HANDLE UNIVERSAL
10	1969-39-25	BUSHING
11	1969-5-13	HANDLE CLIP
12	1969-64-13-119.25	LOCKROD W/ CLIP #11
	1969-64-13-139.25	
FOR SHALLOW HEADER APPLICATION		
14	16437L-13	CAM LH
	16437R-13	CAM RH
15	1401-6517-L	KEEPER LH
	1401-6517-R	KEEPER RH
	16436-SSCL-22	KEEPER LH S/S
	16436-SSCR-22	KEEPER RH S/S

OLD STYLE



Item	Part Number	Description
1	1969-2X-13	CAM
2	1969-1-13	KEEPER
3	4-1969-8-13	BEARING COVER
4	1969-9X-13	BACK PLATE
5	1969-10-13	LOCKROD BRACKET
6	1969-11	BACK PLATE
7	1969-7-13	HANDLE RETAINER
8	1969-4X-13	HANDLE KEEPER
9	GD1969-6XL	HANDLE LH W/ LOGO
	GD1969-6XR	HANDLE RH W/ LOGO
	1969-6X-13	HANDLE UNIVERSAL
10	1969-39-25	BUSHING
11	1969-5-13	HANDLE CLIP
12	1969-64-13-119.25	LOCKROD W/ CLIP #11
	1969-64-13-139.25	
13	1978-9-13	BACK PLATE NOTCHED
FOR SHALLOW HEADER APPLICATION		
14	1974-2X-13	CAM
15	1974-1X-13	KEEPER


EBERHARD LOCKRODS & PARTS



Part Number	Description
1971-22-13	GUIDE FOR 3RD POINT BLADE



Part Number	Description
GD-1979-20-13	BLADE 3RD POINT LOCK



Part Number	Description
1969-64-13-119.25	LOCKROD W/ HANDLE BRACKET
1969-64-13-139.25	



Part Number	Description
2-1978-6-13	CAST HANDLE



Part Number	Description
5625-16	BOLT LOCKROD HANDLE
5625-17	NUT LOCKROD HANDLE



Part Number	Description
4-1971-21-13	KEEPER FOR 3RD POINT BLADE



Part Number	Description
1979-23-13	BRACKET FOR MOUNTING 3RD POINT BLADE